

**11-: Symptom Chart 11**← [11-: Introduction](#)**11-1 OBSERVE CHECK ENGINE LIGHT**

Is CHECK ENGINE light continuously illuminated?

Yes	No
GO to <a href="#">11-2</a> .	GO to <a href="#">11-3</a> .

**11-2 PERFORM KOEO ON-DEMAND SELF TEST AND RETRIEVE/CLEAR CONTINUOUS DTCS**

- Go to [Section 2C](#) , Diagnostic Methods. Perform KOEO On-Demand Self Test, and Retrieve/Clear Continuous DTCs.

Is fault indicated?

Yes	No
GO to appropriate pinpoint test.	GO to <a href="#">11-3</a> .

**11-3 RUN BULB CHECK**

- Cycle ignition switch.

Does CHECK ENGINE light flash?

Yes	No
CHECK ENGINE light is OK.	GO to Pinpoint Test <a href="#">L</a> .

