

Symptom Chart Index

Driveability

System/Symptom		Oasis Number	Chart Number
Starting Concerns	No Crank/Slow Crank	601300	1
	Hard Start/Long Crank/Erratic Start/Erratic Crank	602300	3
	Hard Start/No Start — Dry Reservoir	—	17
	Stall After Start	—	3
	No Start/Normal Crank	603300	3
Unique Idle Concerns	Slow Return to Idle	617400	5
	Rolling Idle	608400	6
	Stalls When Engaging Clutch	—	6
	Fast Idle	619400	7

Driveability — Performance While Driving Concerns

System/Symptom		Oasis Number	Chart Number
Stalls/Quits	Idle	607400	2
	Acceleration	607500	2
	Cruise	607600	2
	Deceleration	607700	2
Runs Rough	Idle	608400	6
	Acceleration	608500	8
	Cruise	608600	8
Misses	Idle	609400	8
	Acceleration	609500	8
	Cruise	609600	8
Buck/Jerk	Acceleration	610500	8
	Cruise	610600	8
	Deceleration	610700	8
Hesitation/Stumble	Acceleration	611500	8
Surge	Acceleration	612500	9
	Cruise	612600	9
Lack/Loss of Power	Acceleration	614500	10
	Cruise	614600	10

Additional Driveability Concerns

System/Symptom	Oasis Number	Chart Number
Engine Will Only Idle	—	4
Poor Fuel Economy	622000	10
CHECK ENGINE Light Concern	698298	11
Speed Control	205200	13

Electrical

System/Symptom		Oasis Number	Chart Number
Warning Indicators	CHECK ENGINE Light	206000	11

Driveline

System/Symptom		Oasis Number	Chart Number
Automatic Transmission Shift Concerns	A/T Upshift Concern	501000	15
	A/T Downshift Concern	502000	15
	Engagement Concern	503000	15

Engine

System/Symptom		Oasis Number	Chart Number
Oil System Concerns	High Oil Consumption	401100	16
	Leaks	401800	16
Exhaust System Concerns	Visible Smoke	403400	12
