


# 13-1 POWER DISTRIBUTION

1997 F-250 HD/350/SUPER DUTY

For diagnostic information, refer to section 18-01 of the Service Manual.


**GASOLINE**



# POWER DISTRIBUTION 13-2

1997 F-250 HD/350/SUPER DUTY

**GASOLINE**




# 13-3 POWER DISTRIBUTION

1997 F-250 HD/350/SUPER DUTY


## GASOLINE

## ENGINE COMPARTMENT FUSE BOX




# POWER DISTRIBUTION 13-4

1997 F-250 HD/350/SUPER DUTY




# 13-5 POWER DISTRIBUTION

1997 F-250 HD/350/SUPER DUTY




# POWER DISTRIBUTION 13-6

1997 F-250 HD/350/SUPER DUTY



# 13-7 POWER DISTRIBUTION


1997 F-250 HD/350/SUPER DUTY



# POWER DISTRIBUTION 13-8

1997 F-250 HD/350/SUPER DUTY

## GASOLINE CALIFORNIA EXCEPT SUPERDUTY






# 13-9 POWER DISTRIBUTION

1997 F-250 HD/350/SUPER DUTY


**DIESEL**



# POWER DISTRIBUTION 13-10

1997 F-250 HD/350/SUPER DUTY

**DIESEL**




\* CALIFORNIA EXCEPT SUPER DUTY  
 \*\* 49 STATES OR SUPER DUTY

SEE GROUNDS 10-6

# 13-11 POWER DISTRIBUTION


1997 F-250 HD/350/SUPER DUTY

**DIESEL**




# POWER DISTRIBUTION 13-12

1997 F-250 HD/350/SUPER DUTY




# 13-13 POWER DISTRIBUTION

1997 F-250 HD/350/SUPER DUTY




# POWER DISTRIBUTION 13-14

1997 F-250 HD/350/SUPER DUTY



# 13-15 POWER DISTRIBUTION

1997 F-250 HD/350/SUPER DUTY




\* GAS (49 STATES OR SUPER DUTY) OR DIESEL  
 \*\* GAS (CALIFORNIA EXCEPT SUPER DUTY)

# POWER DISTRIBUTION 13-16

1997 F-250 HD/350/SUPER DUTY


\* WITH CREW CAB






# 13-17 POWER DISTRIBUTION

1997 F-250 HD/350/SUPER DUTY




# POWER DISTRIBUTION 13-18

1997 F-250 HD/350/SUPER DUTY




# 13-19 POWER DISTRIBUTION

1997 F-250 HD/350/SUPER DUTY




# POWER DISTRIBUTION 13-20

1997 F-250 HD/350/SUPER DUTY




# 13-21 POWER DISTRIBUTION

1997 F-250 HD/350/SUPER DUTY



# POWER DISTRIBUTION 13-22

1997 F-250 HD/350/SUPER DUTY



# 13-23 POWER DISTRIBUTION

1997 F-250 HD/350/SUPER DUTY

