


# 20-1 STARTING SYSTEM

1997 F-250 HD/350/SUPER DUTY

**GASOLINE**


For diagnostic information, refer to section 03-06 of the Service Manual.

Prevents engine startup with clutch engaged.




# STARTING SYSTEM 20-2

1997 F-250 HD/350/SUPER DUTY



# 20-3 STARTING SYSTEM

1997 F-250 HD/350/SUPER DUTY



# STARTING SYSTEM 20-4

1997 F-250 HD/350/SUPER DUTY

