
AH: Symptom Chart 8

[← AH: Introduction](#)**AH1 OBSERVE CHECK ENGINE LIGHT**

Is CHECK ENGINE light continuously illuminated?

Yes	No
GO to AH2 .	GO to AH3 .

AH2 PERFORM KOEO ON-DEMAND SELF TEST AND RETRIEVE/CLEAR CONTINUOUS DTCS

- Go to [Section 2](#) , Diagnostic Methods. Perform KOEO On-Demand Self Test, and Retrieve/Clear Continuous DTCs.

Is fault indicated?

Yes	No
GO to appropriate pinpoint test.	GO to AH3 .

AH3 RUN BULB CHECK

- Cycle ignition switch.

Does CHECK ENGINE light flash?

Yes	No
CHECK ENGINE light is OK.	GO to Pinpoint Test NB .
