

Pinpoint Test Index

Pinpoint Test Letter	Description	Page Number
A	Vehicle Battery	5-12
C	Reference Voltage	5-20
DA	Intake Air Temperature (IAT) Sensor	5-23
DB	Engine Oil Temperature (EOT) Sensor	5-27
DC	Injection Control Pressure (ICP) Sensor	5-32
DD	Accelerator Pedal (AP) Sensor	5-39
DE	Exhaust Back Pressure (EBP) Sensor	5-43
DF	Camshaft Position (CMP) Sensor	5-50
DG	Barometric Pressure (BARO) Sensor	5-54
DH	Manifold Absolute Pressure (MAP) Sensor, Analog	5-56
DI	Manifold Air Temperature (MAT) Sensor — 1999 F-Series	5-61
DJ	Water in Fuel (WIF) Sensor	5-63
DK	Water in Fuel Indicator Lamp (WIFIL)	5-65
DL	Vehicle Speed Sensor (VSS)	5-68
FA	Air Conditioning	5-68
FB	Brake Pressure Applied (BPA) Switch	5-70
FC	Clutch Pedal Position (CPP)/Neutral Start Switch	5-75
FD	Brake Lamp Switch	5-79
FE	Idle Validation Switch (IVS)	5-83
FF	Parking Brake Applied (PBA) Switch	5-86
FG	Speed Control Command Switch (SCCS)	5-90
FH	4x4 Low	5-96
FJ	IDM Electronic Feedback (EF)	5-99
FK	Fuel Pump Monitor/Control	5-104
H	Auxiliary Powertrain Control System	5-110
KA	Cylinder Identification (CID)	5-115
KB	Exhaust Back Pressure Regulator (EPR)	5-120
KC	Glow Plug System	5-124
KD	Glow Plug Lamp (GPL)	5-132
KE	Injection Pressure Regulator (IPR)	5-136
KF	Fuel Delivery Command Signal (FDCS)	5-143
KG	Tachometer — F-Series	5-146
KH	Wastegate Control (WGC) Solenoid — 1999 F-Series	5-149
KJ	Kickdown Solenoid Relay (Allison AT545) Transmission Downshift Function	5-152
KL	Manifold Intake Air (MIA) Heater	5-155
MA	Continuous Memory Failure	5-159
MB	OBD II Readiness Code	5-161
MC	PCM Inactive Background Fault	5-162

MD	PCM-ROM Failure	5-163
ME	PCM Reset	5-???
NA	Injector Driver Circuit Operation	5-164
NB	Check Engine Light	5-177
NC	Injector Driver Module Enable (IDM-EN)	5-180
QA	Unable to Activate Self Test/SCP Communication Error/DTC Not Listed	5-188
QB	Glow Plug System (GPCM) — California	5-191
