

# 20-1 STARTING SYSTEM


2000 EXCURSION, SUPER DUTY SERIES F-250, F-350, F-450, F-550

For diagnostic information, refer to Section 303-06 of the Workshop Manual.

HOT AT ALL TIMES


EXCURSION

\* DIESEL



# STARTING SYSTEM 20-2

2000 EXCURSION, SUPER DUTY SERIES F-250, F-350, F-450, F-550



# 20-3 STARTING SYSTEM

2000 EXCURSION, SUPER DUTY SERIES F-250, F-350, F-450, F-550

