


37-1 SHIFT LOCK

2000 EXCURSION, SUPER DUTY SERIES F-250, F-350, F-450, F-550

For diagnostic information, refer to Section 307-05 of the Workshop Manual.

* EXCURSION
** BRAKE PEDAL POSITION SWITCH CLOSED



With Ignition Switch in RUN, drive is unable to shift the automatic transmission out of PARK, unless the brake pedal is depressed.

Signals Shift Lock Actuator that brake pedal has been depressed.

SEE GROUNDS 10-6, 10-19

SEE GROUNDS 10-6, 10-19

Refer to Location Index, Cell 152, for Component, Connector, Splice, Ground and Base Part Number descriptions and locations.