

Pinpoint Test Index

Pinpoint Test Letter	Description	Page Number
A	Vehicle Battery	5-13
C	Reference Voltage	5-23
DA	Intake Air Temperature (IAT) Sensor	5-26
DB	Engine Oil Temperature (EOT) Sensor	5-30
DC	Injection Control Pressure (ICP) Sensor	5-35
DD	Accelerator Pedal (AP) Sensor	5-42
DE	Exhaust Back Pressure (EBP) Sensor	5-46
DF	Camshaft Position (CMP) Sensor	5-53
DG	Barometric Pressure (BARO) Sensor	5-57
DH	Manifold Absolute Pressure (MAP) Sensor, Analog	5-59
DI	Manifold Air Temperature (MAT) Sensor — 1999 F-Series	5-64
DJ	Water in Fuel (WIF) Sensor	5-66
DK	Water in Fuel Indicator Lamp (WIFIL)	5-68
DL	Vehicle Speed Sensor (VSS)	5-71
DM	Engine Coolant Temperature Sensor (ECT)	5-77
FA	Air Conditioning	5-81
FB	Brake Pressure Applied (BPA) Switch	5-84
FC	Clutch Pedal Position (CPP)/Neutral Start Switch	5-90
FD	Brake Lamp Switch	5-94
FE	Idle Validation Switch (IVS)	5-98
FF	Parking Brake Applied (PBA) Switch	5-101
FG	Speed Control Command Switch (SCCS)	5-105
FH	4x4 Low	5-112
FJ	IDM Electronic Feedback (EF)	5-115
FK	Fuel Pump Monitor/Control	5-120
H	Auxiliary Powertrain Control System	5-126
KA	Cylinder Identification (CID)	5-131
KB	Exhaust Back Pressure Regulator (EPR)	5-136
KC	Glow Plug System	5-140
KD	Glow Plug Lamp (GPL)	5-145
KE	Injection Pressure Regulator (IPR)	5-149
KF	Fuel Delivery Command Signal (FDCS)	5-156
KG	Tachometer — F-Series	5-159
KH	Wastegate Control (WGC) Solenoid — 1999 F-Series	5-162
KJ	Kickdown Solenoid Relay (Allison AT545) Transmission Downshift Function	5-165
KL	Manifold Intake Air (MIA) Heater	5-168
MA	Continuous Memory Failure	5-172
MB	OBD II Readiness Code	5-174

MC	PCM Inactive Background Fault	5-175
MD	PCM-ROM Failure	5-176
ME	PCM Reset	5-???
NA	Injector Driver Circuit Operation	5-177
NB	Check Engine Light	5-190
NC	Injector Driver Module Enable (IDM-EN)	5-193
QA	Unable to Activate Self Test/SCP Communication Error/DTC Not Listed	5-202
QB	Glow Plug System (GPCM) — California	5-205
QC	Electronic Throttle Control (ETC)	5-213
