

Pinpoint Test Index

Pinpoint Test Letter	Description	Page Number
A	Vehicle Battery	5-17
C	Reference Voltage	5-26
DA	Intake Air Temperature (IAT) Sensor	5-30
DB	Engine Oil Temperature (EOT) Sensor	5-34
DC	Injection Control Pressure (ICP) Sensor	5-40
DD	Accelerator Pedal (AP) Sensor	5-48
DE	Exhaust Back Pressure (EBP) Sensor	5-52
DF	Camshaft Position (CMP) Sensor	5-60
DG	Barometric Pressure (BARO) Sensor	5-65
DH	Manifold Absolute Pressure (MAP) Sensor, Analog	5-67
DI	Manifold Air Temperature (MAT) Sensor	5-72
DJ	Water in Fuel (WIF) Sensor	5-74
DK	Water in Fuel Indicator Lamp (WIFIL)	5-76
DL	Vehicle Speed Sensor (VSS)	5-81
DM	Engine Coolant Temperature (ECT) Sensor	5-88
FA	Air Conditioning	5-92
FB	Brake Pressure Applied (BPA) Switch	5-98
FC	Clutch Pedal Position (CPP)/Neutral Start Switch	5-104
FD	Brake Lamp Switch	5-109
FE	Idle Validation Switch (IVS)	5-114
FF	Parking Brake Applied (PBA) Switch	5-117
FG	Speed Control Command Switch (SCCS)	5-121
FH	4x4 Low Range — F-Series/Excursion	5-128
FJ	IDM Electronic Feedback (EF)	5-130
FK	Fuel Pump Monitor/Control	5-136
H	Auxiliary Powertrain Control System	5-142
KA	Cylinder Identification (CID)	5-147
KB	Exhaust Back Pressure Regulator (EPR)	5-152
KC	Glow Plug System	5-156
KD	Glow Plug Indicator Lamp (GPL)	5-161
KE	Injection Pressure Regulator (IPR)	5-167
KF	Fuel Delivery Command Signal (FDCS)	5-174
KG	Tachometer	5-177
KH	Wastegate Control (WGC) Solenoid	5-181
KJ	Kickdown Solenoid Relay (Allison AT545) Transmission Downshift Function	5-185
KL	Manifold Intake Air (MIA) Heater	5-189
MA	Continuous Memory Failure	5-193
MB	OBD II Readiness Code	5-195

MC	PCM Inactive Background Fault	5-196
MD	PCM-ROM Failure	5-197
ME	PCM Reset	5-198
NA	Injector Driver Circuit Operation	5-202
NB	Check Engine Light	5-216
NC	Injector Driver Module Enable (IDM-EN)	5-221
QA	Unable to Activate Self Test/SCP Communication Error/DTC Not Listed	5-228
QB	Glow Plug System (GPCM) — California	5-231
QC	Electronic Throttle Control (ETC)	5-240
